



Installation Instructions for BRP SUB Mount
P/N 9610P3/9616P3

- 1) Place bike on a stand and remove bars and triple clamp.
- 2) Remove bar perches from triple clamp.
- 3) Install frame bracket over head tube and torque per installation instructions supplied with frame bracket.
- 4) Re-install triple clamp only at this time
- 5) Torque steering stem nut and pinch bolts on triple clamp to manufacturer's torque specs.
- 6) Install BRP SUB mount using stock M10 hardware.
- 7) Torque M10 Nylock nuts to manufacturer's torque specs.
- 8) Install Damper using (2) M6 Allen bolts. Damper will need to be mounted in reverse position with body facing towards the rider. For removal of damper arm a puller tool is available.
- 9) Install handlebars and torque bar clamps.
- 10) Check steering for any cable interference and proper function of all controls.
- 11) Check for clearance of tower pin and damper body.

If you have any further questions please feel free to call us or e-mail us and we will be happy to assist you.

3270 Fillmore Ridge Heights #A Colorado Springs, Co 80907
(719) 633-8133 e-mail support@brpmoto.com
For questions or comments please call or e-mail.

WWW.SHOPBRP.COM