



## **980314 SUB MOUNT ADAPTER INSTALLATION INSTRUCTIONS:**

### **WARNING !**

We highly recommend that this procedure be done by a trained motorcycle mechanic. This procedure requires the use of special tools. If any of these components are not installed correctly this could result in serious injury or death. Please ride carefully and always wear a helmet!!!

- 1) Place bike up on a stand and remove the seat and tank.
- 2) Remove handlebars and triple clamp. (Refer to owners manual for removal and installation procedures.)
- 3) Install new SUB mount tower.  
(Follow instructions supplied with tower)
- 4) Assemble and torque SUB mount to triple clamp using supplied hardware.  
SUB Mount will come with pre-installed studs. (Torque 12mm nuts according to your models torque specifications.)
- 5) Position handlebar perches in desired position, either 12 or 22mm in front of steering stem and torque 10mm bolts to 30-35 lb/ft pounds. We recommend using Loc-tite on these bolts.
- 6) Install triple clamp and SUB mount onto bike. Follow owner's manual for torque specifications.
- 7) Install Scott's stabilizer w/ (2) 6mm allen bolts. (Use Loc-tite on bolts)
- 8) Install handlebars and bar clamps, follow owner's manual for torque specifications.
- 9) While bike is on a stand, check that all cables and controls are functioning properly by turning handlebars from lock to lock.
- 10) After initial ride re-torque all bolts