



## **Installation Instructions for BRP SUB Mount** **P/N 9803P3, 9806P3 & 9809P3**

- 1) Place bike on a stand and remove bars and triple clamp.
- 2) Remove bar perches from triple clamp.
- 3) Install frame bracket over head tube and torque per installation instructions supplied with frame bracket.
- 4) Re-install triple clamp only at this time
- 5) Torque steering stem nut and pinch bolts on triple clamp.
- 6) Install BRP SUB mount using new hardware.
- 7) Torque M12 Nylock nuts as follows:  
Solid Mounted triple clamps 35 - 40 ft. Lbs.  
Rubber Mounted triple clamps 24 – 32 ft. lbs.
- 8) Install Damper using (2) M6 Allen bolts Damper will require rotating arm to allow body to face towards the rider.
- 9) Install handlebars and torque bar clamps.
- 10) Check steering for any cable interference and proper function of all controls.
- 11) Check for clearance of tower pin and damper body.

If you have any further questions please feel free to call us or e-mail us and we will be happy to assist you.