



9263-R4 / 9264-R4 / 9265-R4 TRIPLE CLAMP INSTALLATION INSTRUCTIONS

- Support front tire and remove stock upper triple clamp (Refer to owners manual)
- Install BRP top triple clamp.
- Install steering stem washer and nut using a small amount of red loctite and torque to motorcycle manufacturer's specification. (refer to owners manual for torque specification)
- Install fork pinch bolts using a small amount of grease or anti-seize. Torque fork pinch bolts to motorcycle manufacturer's specification (Refer to owner's manual for torque specification.)
- Install handle bars. Install top bar clamps and 8mm bolts using a small amount of grease or anti-seize. Tighten top bar clamp bolts evenly to achieve equal spacing between the bar mount perches and top bar clamps. (Refer to owner's manual for torque specifications.)
- Re-torque all bolts after first ride to ensure tightness. Make checking the torque of all triple clamp, bar mount, and fork pinch bolts part of your routine maintenance.
- Assemble BRP Handlebar Perches and attach to Upper Triple Clamp using M8X45 Hex Head bolts and washer. Use Blue Loc-Tite and torque to 18-20 Ft./Lbs

3270 Fillmore Ridge Heights #A Colorado Springs, Co 80907

(719) 633-8133 e-mail support@brpmoto.com

For questions or comments please call or e-mail.

www.BRPMOTO.COM
