



Lower Triple Clamp Installation Instructions
Important Notice
Read Before Installing

BRP highly recommends that you have your triple clamps installed by a qualified, professional mechanic. Removal and installation of the steering stem and bearing should be done, only, by a qualified mechanic with the proper tools. Failure to do so can cause damage to the steering stem and/or triple clamp assembly, resulting in serious injury or possible death. Any improper methods of installing or removing steering stem will void any and all implied warranties and will release BRP, Billet Racing Products L.L.C. from any and all liability.

3270 Fillmore Ridge Heights Unit A Colorado Springs, Co 80907
(719)633-8133 e-mail support@brpmoto.com
For questions or comments please call or e-mail.

WWW.SHOPBRP.COM



Lower Triple Clamp Installation Instructions
Important Notice
Read Before Installing

BRP highly recommends that you have your triple clamps installed by a qualified, professional mechanic. Removal and installation of the steering stem and bearing should be done, only, by a qualified mechanic with the proper tools. Failure to do so can cause damage to the steering stem and/or triple clamp assembly, resulting in serious injury or possible death. Any improper methods of installing or removing steering stem will void any and all implied warranties and will release BRP, Billet Racing Products L.L.C. from any and all liability.

3270 Fillmore Ridge Heights Unit A Colorado Springs, Co 80907
(719)633-8133 e-mail support@brpmoto.com
For questions or comments please call or e-mail.

WWW.SHOPBRP.COM



